

Tools & Materials Required

- Shower panel kit which includes: trims, adhesive and silicone
- Applicator gun
- Tape measure
- Electric jigsaw or fine tooth saw
- Pencil
- Stanley knife

Step-by-Step Guide

1. Measure then cut the internal corner trim to the desired height of the panel with a fine tooth saw.
2. Place the internal corner on a level surface and apply the adhesive to the outer edges of the trim and fit where required.
3. Measure the bottom trim near the shower tray and cut with a fine tooth saw.
4. Apply adhesive to the back of the Cladseal base trim and silicone to the base of the Cladseal base trim and fit in place.
5. With a tape measure, measure the top, middle and bottom of the wall where it is required to be installed.
6. With a pencil, transfer these measurements onto the panel.
7. With a jigsaw or a fine tooth saw (whichever you prefer), carefully cut the panel to the desired measurements.
8. Place the panel to the wall (with no adhesive) to ensure that it fits well.
9. Once you have ensured it fits in situ, remove the panel and place in a safe place.



Step-by-Step Guide

10. Proceed to apply plenty of adhesive to the wall.
11. Now install the panel against the wall and smooth out all air pockets.
12. Repeat this process for the other wall and any subsequent walls.
13. Measure and cut the side joint trims to the desired length.
14. Apply adhesive and fit in place. These trims slot directly behind the boards.
15. Silicone seal the top of the board where it meets the ceiling.
16. Silicone any gaps around any fixtures or fittings as required.
17. Use washing up liquid and water in a spray bottle, spray over the silicone and gently wipe the excess off with a finger or a damp cloth.
18. Job complete – time for a brew!

Preparation of Walls Panels

We would recommend that us use warm soapy water or a mild household cleaner with a soft cloth to clean your new wall panels.

However, do not use solvent based cleaners, scouring pads or harsh abrasive cleaners as this will damage the panel. Always ensure the panel is rinsed well after cleaning.

The panels must be fitted/adhered to prepared walls (if the walls are newly plastered you must apply PVA to seal the wall so that the glue/adhesive is not absorbed by the plaster resulting in the panels/sheets to come off of the wall), apply good quality adhesive like Igloo adhesive tubs/tubes, to the back of the panel/sheet and apply to the wall ensuring it is level and straight. This procedure must be undertaken when fitting to plaster/plasterboard/wood and other similar substrates.

You must ensure that the adhesive is evenly distributed as per our video and not 'dot and dab' to ensure the panels are securely adhered and a minimum of 2 tubes of adhesive used per panel. For more guidance and advice visit our YouTube page for helpful videos or phone our customer service team on 01709 329117.

